



Installation Instructions

Side cab lights

3 & 4 Function

Installation Notes:

1. Please read all instructions before installing light bar.
2. The following procedure describes a generic (typical) installation.
3. Prior to installation check all parts and inspect bar for damage and/or cracks
4. Lighting laws vary depending on the jurisdiction; check your local laws before installation.
5. Consult your local mechanic or technician if uncertain of wiring or installation of light bar.

Installation

Step 1- Lay the bars next to the vehicle with the wires facing the front of the vehicle

Step 2- Slide the included brackets over the bar. Evenly spacing them across the bar, Be sure not to cover the LED's with the brackets. The bar should be angled downwards slightly.



Step 3- Next you will use the supplied screws. The screws get screwed into the flat metal surface below the door.



Step 4- Now that the bar is installed beneath the vehicle you can start to route the wiring up towards your parking/turn signals. You will want to pull back your fender liner to route the wires into the engine compartment. The following is the color code for the 3 and 4 function side cab lights.

3 Function

Black-ground
White- running
Red- turn signal

4 Function

Black-Ground
Yellow- Running
Red- Turn
White- Courtesy light

Step 5- You will want to remove your corner marker lens/headlight/parking light if you cannot access the harness from the engine bay.

Step 6- Splice the wires to their corresponding wire on the vehicle.



Step 7- Once you have the wires all spliced in you can test them to make sure they are working properly by turning on your running lights then your turn signal and then hazards. Once you have tested all the functions you can put your light back in the vehicle and proceed to the other side.

NOTE:

If you purchase the 4 function side cab light with the courtesy lights. On these bars there is an extra wire coming off each bar. This wire will need to be spliced into your dome light circuit. Please consult a factory service manual for your specific vehicle or have this product professionally installed.

*ANZO warranties against manufacturing defects for 1 year from date of purchase. Return defected product directly to place of purchase with proof of purchase receipt or invoice.

For additional assistance
Please call our customer service at
888.360.3696