



NOTE: due to normal manufacturing processes you may have “flashing” (small fibers of plastic) around the pod holes. Once the gauge(s) are installed in the pod you will not be able to see the “flashing.”

1. Remove the two allen screws on the lower left and right of the vent cover (PHOTO 1)
2. Pull straight back on cover. Carefully use a screwdriver or putty knife at the rear of the cover to apply forward pressure.
3. Wire and install gauges into pod. The gauges are a pressure fit and do not require additional brackets or hardware to hold them into the pod.
4. Run wiring through the cutout located on the left side of the pod.
5. Place pod on dash and press down on back to snap pod in place (PHOTO 2)
6. Reinstall the vent cover over the front lip of the pod (PHOTO 3). Be sure the pins on the back of the cover are in the holes on the dash and the allen screws are reinstalled.

(PHOTO 1)



(PHOTO 2)



(PHOTO 3)



Auto Meter Gauge Works Three Year Limited Warranty

Gauge Works warrants to the consumer that all Auto Meter Gauge Works products will be free from defects in material and workmanship. Products that fail will be repaired or replaced at Auto Meter Gauge Works' option to the consumer, when determined by Auto Meter Gauge Works that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the Auto Meter Gauge Works Product and the necessary labor done by Auto Meter Gauge Works to effect the repair or replacement of the Auto Meter Gauge Works product. In no event shall this warranty exceed the original purchase price of the Auto Meter Gauge Works product nor shall Auto Meter Gauge Works be responsible for special, incidental or consequential damages or costs incurred due to the failure of this product. Warranty claims to Auto Meter Gauge Works must be transportation prepaid and accompanied with proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. Improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. Auto Meter Gauge Works disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by Auto Meter Gauge Works. This warranty is made solely by Gauge Works with Auto Meter being the agent to contact for warranty claims. If the partnership between Auto Meter and Gauge Works dissolves, then all warranty adjustments will be covered by the Gauge Works Co.

FOR SERVICE CONTACT: AUTO METER PRODUCTS Inc. 413 W. Elm St., Sycamore, IL 60178 USA (815)899-0801 or
Email us at service@autometer.com

© 2006 Auto Meter Products, Inc.

2650-1153 05/30/06



NOTE: due to normal manufacturing processes you may have “flashing” (small fibers of plastic) around the pod holes. Once the gauge(s) are installed in the pod you will not be able to see the “flashing.”

1. Remove the two allen screws on the lower left and right of the vent cover (PHOTO 1)
2. Pull straight back on cover. Carefully use a screwdriver or putty knife at the rear of the cover to apply forward pressure.
3. Wire and install gauges into pod. The gauges are a pressure fit and do not require additional brackets or hardware to hold them into the pod.
4. Run wiring through the cutout located on the left side of the pod.
5. Place pod on dash and press down on back to snap pod in place (PHOTO 2)
6. Reinstall the vent cover over the front lip of the pod (PHOTO 3). Be sure the pins on the back of the cover are in the holes on the dash and the allen screws are reinstalled.

(PHOTO 1)



(PHOTO 2)



(PHOTO 3)



Auto Meter Gauge Works Three Year Limited Warranty

Gauge Works warrants to the consumer that all Auto Meter Gauge Works products will be free from defects in material and workmanship. Products that fail will be repaired or replaced at Auto Meter Gauge Works' option to the consumer, when determined by Auto Meter Gauge Works that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the Auto Meter Gauge Works Product and the necessary labor done by Auto Meter Gauge Works to effect the repair or replacement of the Auto Meter Gauge Works product. In no event shall this warranty exceed the original purchase price of the Auto Meter Gauge Works product nor shall Auto Meter Gauge Works be responsible for special, incidental or consequential damages or costs incurred due to the failure of this product. Warranty claims to Auto Meter Gauge Works must be transportation prepaid and accompanied with proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. Improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. Auto Meter Gauge Works disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by Auto Meter Gauge Works. This warranty is made solely by Gauge Works with Auto Meter being the agent to contact for warranty claims. If the partnership between Auto Meter and Gauge Works dissolves, then all warranty adjustments will be covered by the Gauge Works Co.

FOR SERVICE CONTACT: AUTO METER PRODUCTS Inc. 413 W. Elm St., Sycamore, IL 60178 USA (815)899-0801 or
Email us at service@autometer.com

© 2006 Auto Meter Products, Inc.

2650-1153 05/30/06